



## Installation Instructions for AFCO Coil Over Stud Top Upper Shock Mount

### To Install Stud Assembly

1. Remove all parts above the large washer (gold in color).
2. Insert shock through from bottom of chassis.
3. Chassis should be resting on the large washer. (gold in color)
4. Re-install rubber bushing, smaller of the two large washers and a nut.
5. Tighten nut.
6. If your shock has two of the black nuts, tighten the first one and then using a second 13/16" wrench tighten the two nuts against each other to prevent the nuts from loosening.
7. Re-install remaining components.
8. Adjust knob (on adjustable shocks) to ensure that the knob moves freely.

